

Food Service & Restaurant Cleaning Solutions



Heavy Duty Lime & Scale Remover



Core 3: Personal Attention

Every customer requires special attention and has their own demands put on them. Our staff will design and implement a program designed to fit your needs.

Core 3: Experience

With our full staff of formulators, chemists, & marketing professionals we have been bringing cutting edge products to market for over 70 years.

Core 3:Technology

Through daily contact with industry professionals, we are continuously updating and improving our products to make sure you perform at your best.



Synthetic Labs offers industry-leading solutions for businesses and professionals who demand exceptional results.

DISHWASHING

Novel Descaler

Heavy Duty Lime & Scale Remover

What is Novel Descaler?

Descale is use for descaling and deliming dishwashers and steam tables, cleaning stainless steel and aluminum, and descaling coffee urns. This acid based cleaner is great for all your mineral and lime removing needs. Will not harm stainless steel or glass.

BENEFITS:

- Removes minerals on contact.
- Highly concentrated and easy to use.
- Removes stains from coffee cups & urns.
- Will remove hard water stains from glasses.
- Versatile for many different applications.

DIRECTIONS FOR USE:

For institutional or commercial use.

DO NOT MIX WITH OTHER CHEMICALS.

For institutional or commercial use only. Before use, read product label and Safety Data Sheet. Consult your local representative for specific use and setup instructions if you are not experienced at descaling dish machines.

See Descaling procedures for proper use. Make sure to wear Personal Protective Equipment.

Descaling Procedures:

- 1. Empty the dishwasher completely before starting the descaling process.
- 2. Clean the bottom filter by removing it from the dishwasher, rinsing it under hot tap water, and scrubbing it gently with a toothbrush and a non-corrosive dishwashing detergent.
- 3. Add 40 to 64 ounces of descaling solution to the tank inside the mchine. If unsure on amount to be added or where to add the soltuion, please contact your representaive for guidance. DO NOT attempt to decale the machine if you are not experienced at doing so.
- 4. Run for 10-15 minutes. Make sure there is adequate ventilation in the room to eliminate any fumes caused by the descaling. Once the cycle is done, wait to open the machine. Once it is safe to open, leave the dishwasher open overnight to ensure any remaining odors dissipate.

Tech Specs:

| Color | Green |
|-------------------|---------------------|
| Fragrance | Acidic |
| Form | Liquid |
| Phosphates | None |
| FlashPoint | 212°F |
| pH | 1-2 |
| Specific Gravity1 | $.05 \text{ g/m}^3$ |
| Viscosity | Thin |
| Foam | Low |
| Biodegradable | 100% |
| Shelf Life | >1 Year |

| Available Packages | |
|--------------------|-----------------------|
| 6335-4 | 4x1 Gallon Case |
| 6335-5 | 5 Gallon Plastic Pail |



Toll Free: 800-255-4050 24 Victory Lane, Dracut, MA 01826 www.syntecpro.com