



Building & Facilities Maintenance Products



DISINFECTANT

# GC-2100

One-Step Disinfectant Ready-To-Use

CORE 3

### **Core 3: Personal Attention**

*Every customer requires special attention and has their own demands put on them. Our staff will design and implement a program designed to fit your needs.*

### **Core 3: Experience**

*With our full staff of formulators, chemists, & marketing professionals we have been bringing cutting edge products to market for over 70 years.*

### **Core 3: Technology**

*Through daily contact with industry professionals, we are continuously updating and improving our products to make sure you perform at your best.*

Synthetic Labs offers industry-leading solutions for businesses and professionals who demand exceptional results.



# DISINFECTANT

## GC-2100

### One-Step Disinfectant Ready-To-Use

E.P.A. Reg. No. 6836-152-9619 E.P.A. EST. NO. 9619-MA-1

#### WHAT IS GC-2100?

GC-2100 is a Ready-to-Use disinfectant spray & wipe formula that cuts through tough grease & grime. Fast drying, leaves no residue. Use GC-2100 in Homes, Athletic facilities, Hotels, Institutional facilities, Health care facilities and Airports. Use on washable, hard nonporous surfaces of: counters, metal, upholstery, vinyl, plastic, glass and painted surfaces. Use on soft surfaces of: fabric, chairs, seat cushions and upholstered furniture. As a disinfectant, GC-2100 is effective against: *Pseudomonas aeruginosa*, *Salmonella enterica*, *Staphylococcus aureus* - Methicillin Resistant (MRSA), *Enterococcus faecalis* - Vancomycin resistant, \*Hepatitis B Virus, \*Hepatitis C Virus \*Norwalk Virus (Norovirus) \*HIV-1, Influenza Virus Type A/Hong Kong, Human coronavirus and SARS-Related Coronavirus 2 (cause of Covid 19). Is a proven soft surface sanitizer<sup>1,2</sup> against: *Staphylococcus aureus* and *Enterobacter aerogenes*.

#### DIRECTIONS FOR USE

It is a violation of Federal law to use this product in a manner inconsistent with its labeling.

To Disinfect: Apply GC-2100 undiluted to hard, non-porous surfaces, thoroughly wetting the surfaces with a cloth, mop, sponge, sprayer or by immersion. Treated surfaces must remain visibly wet for 10 minutes. For Influenza Virus Type A, Human Coronavirus and SARS-CoV-2, treated surface must remain visibly wet for 1 minute. Wipe dry with a clean cloth or sponge or allow to air dry. For visibly soiled areas, a pre-cleaning is required. For sprayer applications, use a coarse spray device. Spray 6-8 inches from surfaces. Avoid breathing spray.

Rinse all surfaces that come in contact with food such as countertops, appliances, tables and stovetops with potable water before reuse. Do not use on utensils, glassware and dishes.

This product is not for use on medical device surfaces.

To Sanitize Soft Surfaces<sup>1</sup>: Hold bottle 6" - 8" from surfaces and spray until fabric is wet. Fabric must remain visibly wet for 5 minutes. Allow fabric to air dry. Visibly soiled areas must be cleaned prior to sanitizing.

\*KILLS HIV-1 AND HBV AND HCV ON PRE-CLEANED ENVIRONMENTAL SURFACES / OBJECTS PREVIOUSLY SOILED WITH BLOOD / BODY FLUIDS in health care settings or other settings in which there is an expected likelihood of soiling of inanimate surfaces / objects with blood or body fluids and in which the surfaces / objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of Human Immunodeficiency Virus Type 1 [HIV-1] [associated with AIDS] or Hepatitis B Virus [HBV] or Hepatitis C Virus [HCV].

Special Instructions for Cleaning and Decontamination against HIV-1 or HBV or HCV on Surfaces / Objects Soiled With Blood / Body Fluids.

Personal Protection: Clean-up must always be done wearing protective gloves, gowns, masks and eye protection.

Cleaning Procedure: Blood and other body fluids containing HIV or HBV or HCV must be thoroughly cleaned from surfaces and objects before application of GC-2100. Contact Time: Leave surface wet for 1 minute for HIV-1 and 10 minutes for HBV and HCV. Use a 10 minute contact time for disinfection against all other viruses, bacteria and fungi claimed.

Disposal of Infectious Material: Blood, body fluids, cleaning materials and clothing must be autoclaved and disposed of according to local regulations for infectious waste disposal.

#### Tech Specs:

Color.....Yellow  
 Fragrance.....Citrus  
 Form.....Liquid  
 Phosphates.....None  
 FlashPoint.....212F  
 pH.....10.5  
 Specific Gravity.....1.00  
 Viscosity.....Thin  
 Foam.....Moderate  
 Biodegradable.....100%



Toll Free: 800-255-4050

24 Victory Lane, Dracut, MA 01826

www.syntecpro.com